How to use RF Booster Pad

Put 1 sheet of RF Booster Pad onto the treatment head and hold it in place with a cotton stopper.





*Always attach or remove the pad while the power is off or in standby mode.

Modes to use with

Deep Cleanse: CLEAN mode

[How to use] After cleansing your face, wipe off water from your skin before use. After use, do not wipe or wash away. Move onto the next skincare regime.

*After finishing one mode, change to a new sheet if you wish to apply another mode.

Clear Deep Moisture : MOISTURE mode, EMS UP mode, RF mode

[How to use] Use on clean skin. After use, allow the left-over skincare to blend with your skin.

*You may use the same sheet for two modes without changing to a new one.

SZ-PF-1420F